



New from Hanwell is the rl5000 dp radiotelemetry transmitter, designed for use with the Radiolog 8 environmental monitoring system. The units are in IP65-rated cases and are suitable for use in tough environments.

Utilising an integral temperature compensated pressure sensor the rl5000 differential pressure transmitter delivers exceptional performance. The sensor utilises a silicon, micro machined, stress concentration enhanced structure to provide a very linear output to the measured pressure. The ports are designed with matched dead volumes. This series is intended for use with non-corrosive, nonionic working fluids such as clean dry air, dry gases and the like.

The media wetted materials are the silicon diaphragm, glass filled nylon, RTV and alumina ceramic. The transmitter ID, transmission speed and calibration data is programmed into its onboard memory using Radiolog 8, a software package which automatically recognises the type of unit connected to the PC via the USB lead.

Fitted with a custom-designed LCD to indicate current readings, battery life remaining and alarm conditions. There is an instantaneous display update button located on the front panel. Pressure connections are made via quick release Lemo pressure connectors, which avoid damage to the pressure sensor when disconnecting for calibration.

The transmitter is typically powered by a 2.7V 2700mAh battery pack, which can be fitted by the user. The battery life will be dependant on the transmission speed. Larger battery packs are available, local power input is also an option. An indicator on the LCD will warn when the battery is low, and the transmitter maintains a record of when the battery has been changed. The rl-5000 range has been designed to comply with the RoHS and WEEE EU directives, and carries the CE mark.



rl5000 differential pressure

Product Code RL5101-xxx MHz
Series rl5000
¹ Not available in US
² Only available in US

Typical Applications

- ° Measuring positive, negative and differential pressures
- ° Pharmaceutical industry
- ° Clean rooms
- ° Laboratories

Instrument

Dimensions: 197 x 106 x 60mm
Weight: 300 grams
Case Material: ABS
Power Supply: 2.7V 2700mAh Alkaline battery pack
Op. Humidity
Range: 0...95% RH, non-condensing
Op. Temp. Range: -20 °C to +60 °C (fully compensated)

Pressure Sensor

Type: Miniature silicon sensor
Range: +/- 50 Pa (other ranges available on request)
Accuracy: +/-0.5 Pa
Resolution: 0.1 Pa
Pressure connector: 2 x Lemo pressure connectors

Radio

***Radio Frequency:** Fixed frequency modules
 434.075 MHz¹
 433.920 MHz
 Synthesised modules
 433.875 to 434.650 MHz
 in 25KHz increments¹
 458.650 MHz²
Radio power: 10 mW
Radio range: 3 km over open ground

Communications & Software

PC Software: 32 bit Windows
Minimum O/S: Windows 2000, Windows XP, Windows NT

Accessories

Code
Y055 USB communications lead
W250 USB configuration tool (required for users with software earlier than 8.3)
Y123 rl-5000 wall mounting bracket
V133 Red silicone tubing
V134 Blue silicone tubing