

## ACCESSORIES

### Meteo-Online

#### Part number: 9.1700.98.x01

The operation of the program is context-sensitive, i.e. by pressing the right mouse button there are menus displayed in a window, which allow specific settings.

Meteo-Online provides several options for configuration and start of the archive. Hour's- as well as day's-files can be written with settable averaging times.



Meteo-Online is divided into two programs:

- Server
- Visualization

These two independent programs exchange data, where the server has the function to pre-process the data from the connected instruments, to file and to provide them for the visualization (client). The visualization, on the other hand, inquires data cyclically from the server, and presents them in graphic form.

Meteo-Online is internally divided into two programs:

- This concept has the following advantages:
- The server is able to document data without visualization.
- The server is able to administrate several terminals at the same time (limited only by the number of physical interfaces).
- Server and visualization can run on different computers in a network
- Several visualizations can access simultaneously to one server.
- The server is started automatically on booting the PC, and documents the data in the background
- The visualization is started only on request.

### Specification

#### Part number: 9.1700.98.x01

##### Data display

Monitor - display

- Values
- Diagrams
- Tables
- Windrose
- Time
- Date

##### Compatibility

Connectable instruments

- US-Anemometer
- Datalogger
- Clima Sensor
- Weather station WSC11
- Wind display
- etc.

System requirements	PC mit - Prozessor > 1 GHz - RAM > 1 GB
Operating system	- Windows 2003 SP2 - Windows Server 2008 - Windows 7 - Windows Server 2008 R2 - Windows 7 SP1 - Windows Server 2008 R2 SP1 - Windows 8 - Windows 10

## Versions

As per 9.1700.98.x01, but:

### Product number 9.1700.98.001

#### Software

Function	Full version without data monitor
----------	-----------------------------------

### Product number 9.1700.98.101

#### Software

Function	Full version with data monitor
----------	--------------------------------

### Product number 9.1700.98.201

#### Software

Function	Demo version with data monitor
----------	--------------------------------

## Accessories

No accessories are available for this product.

